

SITE MANAGER DEVICE:

CONNECTING PS OFFICE AND THE MACHINE FOR REMOTE ASSISTANCE

SERIAL EXTENSION CABLE:

CONNECTING THE SITE MANAGER WITH THE SE/MPI CONVERTER